

High Speed Digital Signal Processing - the Bedlam Board


**Paul Roberts – CASS Engineering
Development Group**

EoR Workshop November 2012

Introduction

- Background on the Bedlam System
 - Developed for a lunar Cherenkov experiment at Parkes
 - Influenced design choices and peripherals
 - General purpose enough for many applications
 - Used in several observation and measurement applications including EoR
 - Representative of typical DSP backend available for EoR experiments


Bedlam DSP Board



Bedlam Key Specifications

- 8 input channels at 512 MHz bandwidth
 - 4 input channels 1024 MHz bandwidth
- 2 x EV8AQ160 8-bit quad channel 1.25 GHz ADC
- RF input bandwidth DC-2GHz (-3dB)
- 4 x XC5VSX95T DSP oriented FPGAs
- 1 x XC5VLX30T I/O FPGA
- Simple parallel control/data interface to external PCI card
- Dual 1 Gbit optical SFP ethernet interface
- Add on mezzanine interface to 16 x 3.75 Gbit/s transceivers per DSP FPGA (10 GbE CX4 etc)
- Power 75W @ 12V DC or AC

Bedlam System Schematic



DSP Resources per SX95 (4 off)

SLICES (4 LUTs 4 FFs)	14,720
RAM	8784 kbit
MULTIPLIERS (25x18)	640
3.65 Gbit/s Serial I/O	16
Ethernet MAC	4

Example

2 input 4096 channel DFB auto/cross correlator
(2 auto / 1 cross with 64 bit accumulators)


SLICES (67%)

MEMORY (81%)



MULTIPLIERS (37%)

Typical Operation Modes

Transient Mode



Spectrometer/Correlator Mode



Several reference designs

Features

Attractive features

Simple standalone instrument – 2U Rack case

Easy to understand and use

Simple to manufacture

Reference designs available

Can use open source (CASPER) high-level DSP blocks for easy adoption and customization

Limitations

No external memory on board


Applications

High Energy Particle detection via radio Cherenkov emission - Ekers et al


UHE neutrino/CR
> 10^{20} eV





radio photon




Parkes 21cm Multibeam Experiment




Parke: RFI pulse



Parke: Possible Event




Applications – Spectral RFI Monitoring



4096 Channel DFB Spectrometer - Band 800-1000MHz

Applications - Precision system testing


ASKAP RFoF link stability



Applications - Precision system testing


ASKAP RFoF link stability

Phase @ 1.4 GHz vs time



Applications - Precision system testing


ASKAP RFoF link stability



Amplitude @ 1.4 GHz vs time




Mechanical perturbation
– oscillating pedestal fan

Phase @ 1.4 GHz vs time




Measurement variance -
0.001 db
0.001 deg

Applications-Transient RFI Monitoring and Mitigation



Parkes 0.5-6GHz survey
Booldy RFI site monitor

Applications-Transient RFI decoding – Aircraft Tracking




Use in cross-correlation

Question of input coupling in cross-correlation mode

ADC has inter-channel isolation typically -57 db from datasheet

⇒ Voltage coupling ~ 0.001

⇒ Correlator multiplies voltages



Compare with other uwave components in coupled signal chain

⇒ Include in model and/or
Use phase switching to reduce

Current developments

EoR – other talk

- BIGHORNS
- Self-Calibrating receiver –Keith's talk

Short pulse calibration methods -Nipanjana

broadband pulses

can be gated out


simple identification of discontinuities

unambiguous time/phase

other uses-

direct ionospheric dispersion (TEC) measurement etc ?

Pulse calibration




Pulse calibration – making pulses



Pulse width : 350 ps

Pulse amplitude 400 mV
into 50 ohm.




Pulse calibration – making pulses



Pulse amplitude 700V into
50 ohm (10kW).

Pulse rise time 950 ps



Summary

Real-time digital signal processing can help solve many of the problems encountered in EoR experiment design

Cheap, easy to use hardware platforms exist.

Should be fully exploited

CASS Engineering Development Group

Dr. Paul Roberts

Phone: 61 2 9372 4365

Email: paul.roberts@csiro.au

Web: www.csiro.au/org/cass

www.csiro.au

Thank you

Contact Us

Phone: 1300 363 400 or +61 3 9545 2176

Email: enquiries@csiro.au Web: www.csiro.au

